

25557 CLAMP-ON FLOW METER PURGE RETROFIT KIT



Purge flow meter is on bottom



Remove old water meter



Remove pipe back to elbows



Remove right side back to valve



Install new pipe and Clamp-on Flow Meter as pictured. Connect existing cable to meter face.

Note: These instructions should generally work for the “fresh water” flow meter which is located above the purge water meter. The meters are programmed differently, so make sure your meter is installed in the correct location.